PDF-R FlexRay Protocol Decode and SI Analysis Software

1.188 = 0 - 		Z Z Z	oad: 4			1940 1940 1940			118 ⁵ 1185	ľ		2	2036e-3
	4 0.002015			0.00202			0.002025			00203		0.002035	0.0020383
Data: 0x4	A,OxAA,OxAA,	.0x44,0x44,0x	4A,0xAA,0x	ΑΑ,							4		e tails vtes: 20, 71, 8, E5, BE vtes: B6, 59, F2
				2E-09 - 0 - -5E-09 -					Timing Measurements Rise Time: 13.312 n8 Fall Time: 15.107 nS TSS Duration: 902.56 nS Frame Time: 16.934 µS Avg Bit Time: 104.53 nS			Sync Measurements Previous Sync: -314.95 µS Next Sync: 3.6949 mS Previous Cycle Frame: -4.9454 mS Next Cycle Frame: 5.0001 mS Close	
Prodigy Te Option H	telp	- PDF-R Flex	Ray Prot	ocol Analy:	sis Solution	_				_		_	
_	00000										V Botail V	i our	
Decode M		idPr NullFr <u>am</u>	Sync <u>Fr</u> .	am Star <u>tU</u>	pFr Fram <u>eII</u>) Paylo <u>ad</u>	L Heade <u>rC</u>	t Cycl <u>eC</u>	ou Timestam	Data 🔺	🗹 Detail V	iew	Single Run
Decode M		dPr NullFram	SyncFr-	am StartU O	pFr FrameII 101	Payload	L HeaderCF 834	CycleC 62	ou Timestam 1.7959	Data 🔺 0x3E	🗹 Detail V	iew	
ecode M Reser	rved Payloa	the second second second second second	and the second second								💆 Detail V	1.00	Single Run Sequence
ecode M Reser O	rved Payloa O	1 1 1	0	0	101	16	834	62	1.7959 1.9127 1.9471	0x3E	🗹 Detail V	1ew	
Decode M Reser O O	rved Payloa 0 0	1 1 1 1	0	0 0 0 0	101 110 111 112	16 4 4 4	834 431 90 611	62 62 62 62	1.7959 1.9127 1.9471 1.9811	0x3E 0xF , 0xFF 0x0 ,	Detail V	iew	
Decode M Reser 0 0 0 0 0	rved Payloa 0 0 0 0 0 0	1 1 1 1 1	0 0 0 0 0	0 0 0 0 0	101 110 111 112 113	16 4 4 4 4 4	834 431 90 611 918	62 62 62 62 62 62	1.7959 1.9127 1.9471 1.9811 2.0155	0x3E 0xF , 0xFF 0x0 , 0xAA	_		Sequence
Decode M Reser 0 0 0 0 0 0 0	rved Payloa 0 0 0 0 0 0 0 0	1 1 1 1 1 1	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0	101 110 111 112 113 222	16 4 4 4 4 4 127	834 431 90 611 918 1403	62 62 62 62 62 62 62	1.7959 1.9127 1.9471 1.9811 2.0155 2.7929	0x3E 0xF , 0xFF 0x0 , 0xAA 0x3E	☑ Detail V Searc		Sequence
Decode M Reser 0 0 0 0 0	rved Payloa 0 0 0 0 0 0	1 1 1 1 1	0 0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	101 110 111 112 113 222 233	16 4 4 4 4 127 8	834 431 90 611 918 1403 805	62 62 62 62 62 62 62 62 62	1.7959 1.9127 1.9471 1.9811 2.0155 2.7929 3.1435	0x3E 0xF, 0xFF 0x0, 0x0, 0x3E 0x3E	Searc)	h	Sequence
Decode M Reser 0 0 0 0 0 0 0 0 0 0	rved Payloa 0 0 0 0 0 0 0 0 0 0	1 1 1 1 1 1 1 1	0 0 0 0 0 0 0 0	0 0 0 0 0 0 0	101 110 111 112 113 222	16 4 4 4 4 4 127	834 431 90 611 918 1403	62 62 62 62 62 62 62	1.7959 1.9127 1.9471 1.9811 2.0155 2.7929	0x3E 0xF , 0xFF 0x0 , 0xAA 0x3E	_	h	Sequence
Decode M Reser 0 0 0 0 0 0 0 0 0	rved Payloa 0 0 0 0 0 0 0 0 0 0	1 1 1 1 1 1 1 1 1	0 0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0	101 110 111 112 113 222 233	16 4 4 4 4 127 8	834 431 90 611 918 1403 805	62 62 62 62 62 62 62 62 62 62	1.7959 1.9127 1.9471 1.9811 2.0155 2.7929 3.1435	0x3E 0xF, 0xFF 0x0, 0x0, 0x3E 0x3E	Searc)	h	Sequence

Engineers involved in designing and integrating in-vehicle network can monitor protocol information in hex and decimal format of FlexRay signal. Analyze the electrical characteristics of FlexRay signal using eye diagram, time interval error and sync measurements using a Windows based Tektronix Oscilloscope along with the *FlexRay Protocol decode and signal integrity analysis software*.

PDF-R FlexRay Protocol decode and Signal Integrity software offers industry best solution for debugging and testing FlexRay signals using high performance windows based Tektronix oscilloscopes DPO5000/7000/70000.

This software enables the designer to capture thousands of FlexRay messages and display the decoded data. PDF-R FlexRay decode feature allows the users to view the decoded data in hex format and decimal format as configured by user. Overlapping the decoded data on waveform viewing it simultaneously on waveform would enable to locate the inaccurate signal transitions

Signal Integrity:

Electronics should work in extreme operating conditions in an automobile. To ensure this performance, FlexRay signals at physical layer should have enough design margins.

PDF-R Software's signal Integrity features quickly helps in analyzing electrical characteristics of FlexRay signal. The advanced features Eye diagram analysis, time interval



PDF-R FlexRay Protocol Decode and SI Analysis Software

error, and sync measurements in PDF-R software enables user to know the eye opening, jitter, and synchronization sequence in a FlexRay network

Advanced Debug Capabilities:

The powerful PDF-R software enables the designer to locate the cause of the problem using advanced analysis capabilities. The software based trigger features enable user to focus on desired information FlexRay to locate a problem. The distinguished view of eyediagram for selected frame and for the entire data helps in locating problem to a node. Simultaneous view of decoded data with waveform with color distinction helps to locate protocol decodes problems due to problem electrical characteristic of signals.

Features: Protocol Decode

- Converts time domain waveform information into data domain and displays the contents in FlexRay message format
- Simultaneous waveform and decoded data display in single window allows efficient debugging
- Ability to link any FlexRay frame or any message (data or address) to waveform allows efficient analysis of FlexRay communication
- PDI waveform window plots the waveform and display '1' and '0' annotation in zoomed waveform window
- Search function helps in quickly locating the specific data or address in thousands of decoded FlexRay messages
- Time stamp with reference to trigger position allows users know the timing from the trigger position
- Software based trigger features enables user to view the decoded data
- Software trigger features enable the user to set trigger on content of the FlexRay frame, Null frame or a sync frame, CRC error
- Offline analysis with the Ref waveforms, .wfm (Tektronix Oscilloscope's internal waveform file format) and csv files.
- Capability to save the decoded messages in CSV format.

Features: Signal Integrity

- Ability to view the eye diagram for slected message with the complete acquired data helps in pinpointing the cause.
- Time interval error analysis for each frames helps in understanding influence of oscillator stability in each FlexRay node
- Sync measurements enables user to know time laps between the sync frames
- Average bit time measurement



PDF-R FlexRay Protocol Decode and SI Analysis Software

Ordering Information:

PDF-R FlexRay Protocol Decode and SI Software Includes: CD with Software

Oscilloscopes Supported:

Tektronix make Oscilloscopes

- DPO5000 Series
- DPO7000/7000 Series

